

Net Bottom Cage Inserts

Materials

PVC piping & elbows (ADD PVC SIZE INFO)
nylon netting (1/4" – 1/2")
wood screws (ADD LENGTH)

Instructions

- Make rectangle frame out of PVC piping and elbows.
 - Be sure to measure the desired size of the insert by the "outside" measurement of the frame
- Attach screws to the underside of the frame
 - Leave the screws with approximately 1/8" exposed, creating a peg
 - Space the screws evenly, approximately 3"– 4" apart
- Stretch nylon netting tightly over the frame and secure by looping the netting over the screw heads

Netting Suppliers

Christenson Net Works
4074 Sucia Dr.
Ferndale, WA 98248

Schuco Inc. (Manufacturer)
1419 Expressway Drive North
Toledo, OH 43216